

This document is a review generated by EVS

Digital addressable lighting interface - Part 103:  
General requirements - Control devices

## ESTI STANDARDI EESSÕNA

## NATIONAL FOREWORD

See Eesti standard EVS-EN 62386-103:2015 sisaldb Euroopa standardi EN 62386-103:2014 ingliskeelset teksti.	This Estonian standard EVS-EN 62386-103:2015 consists of the English text of the European standard EN 62386-103:2014.
Standard on jõustunud sellekohase teate avaldamisega EVS Teatajas	This standard has been endorsed with a notification published in the official bulletin of the Estonian Centre for Standardisation.
Euroopa standardimisorganisatsioonid on teinud Euroopa standardi rahvuslikele liikmetele kättesaadavaks 19.12.2014.	Date of Availability of the European standard is 19.12.2014.
Standard on kättesaadav Eesti Standardikeskusest.	The standard is available from the Estonian Centre for Standardisation.

Tagasisidet standardi sisu kohta on võimalik edastada, kasutades EVS-i veebilehel asuvat tagasiside vormi või saates e-kirja meiliaadressile [standardiosakond@evs.ee](mailto:standardiosakond@evs.ee).

ICS 29.140.50, 29.140.99

Standardite reproduutseerimise ja levitamise õigus kuulub Eesti Standardikeskusele

Andmete paljundamine, taastekitamine, kopeerimine, salvestamine elektroonsesse süsteemi või edastamine ükskõik millises vormis või millisel teel ilma Eesti Standardikeskuse kirjaliku loata on keelatud.

Kui Teil on küsimusi standardite autorikaitse kohta, võtke palun ühendust Eesti Standardikeskusega:  
Aru 10, 10317 Tallinn, Eesti; koduleht [www.evs.ee](http://www.evs.ee); telefon 605 5050; e-post [info@evs.ee](mailto:info@evs.ee)

The right to reproduce and distribute standards belongs to the Estonian Centre for Standardisation

No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying, without a written permission from the Estonian Centre for Standardisation.

If you have any questions about copyright, please contact Estonian Centre for Standardisation:

Aru 10, 10317 Tallinn, Estonia; homepage [www.evs.ee](http://www.evs.ee); phone +372 605 5050; e-mail [info@evs.ee](mailto:info@evs.ee)

December 2014

ICS 29.140; 29.140.50

English Version

Digital addressable lighting interface -  
Part 103: General requirements - Control devices  
(IEC 62386-103:2014)

Interface d'éclairage adressable numérique -  
Partie 103: Exigences générales - Dispositifs de commande  
(CEI 62386-103:2014)

Digital adressierbare Schnittstelle für die Beleuchtung -  
Teil 103: Allgemeine Anforderungen - Steuergeräte  
(IEC 62386-103:2014)

This European Standard was approved by CENELEC on 2014-12-12. CENELEC members are bound to comply with the CEN/CENELEC Internal Regulations which stipulate the conditions for giving this European Standard the status of a national standard without any alteration.

Up-to-date lists and bibliographical references concerning such national standards may be obtained on application to the CEN-CENELEC Management Centre or to any CENELEC member.

This European Standard exists in three official versions (English, French, German). A version in any other language made by translation under the responsibility of a CENELEC member into its own language and notified to the CEN-CENELEC Management Centre has the same status as the official versions.

CENELEC members are the national electrotechnical committees of Austria, Belgium, Bulgaria, Croatia, Cyprus, the Czech Republic, Denmark, Estonia, Finland, Former Yugoslav Republic of Macedonia, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, the Netherlands, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turkey and the United Kingdom.



European Committee for Electrotechnical Standardization  
Comité Européen de Normalisation Electrotechnique  
Europäisches Komitee für Elektrotechnische Normung

CEN-CENELEC Management Centre: Avenue Marnix 17, B-1000 Brussels

## Foreword

The text of document 34C/1100/FDIS, future edition 1 of IEC 62386-103, prepared by SC 34C "Auxiliaries for lamps" of IEC/TC 34 "Lamps and related equipment" was submitted to the IEC-CENELEC parallel vote and approved by CENELEC as EN 62386-103:2014.

The following dates are fixed:

- latest date by which the document has to be implemented at national level by publication of an identical national standard or by endorsement (dop) 2015-09-12
- latest date by which the national standards conflicting with the document have to be withdrawn (dow) 2017-12-12

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. CENELEC [and/or CEN] shall not be held responsible for identifying any or all such patent rights.

## Endorsement notice

The text of the International Standard IEC 62386-103:2014 was approved by CENELEC as a European Standard without any modification.

In the official version, for Bibliography, the following notes have to be added for the standards indicated:

CISPR 15	NOTE	Harmonized as EN 55015.
IEC 60598-1	NOTE	Harmonized as EN 60598-1.
IEC 60669-2-1	NOTE	Harmonized as EN 60669-2-1.
IEC 60921	NOTE	Harmonized as EN 60921.
IEC 60923	NOTE	Harmonized as EN 60923.
IEC 60929	NOTE	Harmonized as EN 60929.
IEC 61347-1	NOTE	Harmonized as EN 61347-1.
IEC 61347-2-3	NOTE	Harmonized as EN 61347-2-3.
IEC 61547	NOTE	Harmonized as EN 61547.
IEC 62034	NOTE	Harmonized as EN 62034.

**Annex ZA**  
(normative)

**Normative references to international publications  
with their corresponding European publications**

The following documents, in whole or in part, are normatively referenced in this document and are indispensable for its application. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

NOTE 1 When an International Publication has been modified by common modifications, indicated by (mod), the relevant EN/HD applies.

NOTE 2 Up-to-date information on the latest versions of the European Standards listed in this annex is available here:  
[www.cenelec.eu](http://www.cenelec.eu)

<u>Publication</u>	<u>Year</u>	<u>Title</u>	<u>EN/HD</u>	<u>Year</u>
IEC 62386-101	2014	Digital addressable lighting interface - Part 101: General requirements - System Components	EN 62386-101	2014
IEC 62386-102	2014	Digital addressable lighting interface - Part 102: General requirements - Control gear	EN 62386-102	2014

## CONTENTS

FOREWORD.....	11
INTRODUCTION.....	13
1    Scope .....	15
2    Normative references .....	15
3    Terms and definitions .....	15
4    General .....	18
4.1    General.....	18
4.2    Version number .....	18
5    Electrical specification .....	18
6    Interface power supply .....	18
7    Transmission protocol structure.....	18
7.1    General.....	18
7.2    24 bit forward frame encoding .....	19
7.2.1    Frame format for instructions and queries .....	19
7.2.2    Frame format for event messages.....	20
8    Timing .....	21
9    Method of operation.....	21
9.1    General.....	21
9.2    Application controller .....	21
9.2.1    General .....	21
9.2.2    Single-master application controller .....	22
9.2.3    Multi-master application controller .....	22
9.3    Input device .....	22
9.4    Instances of input devices.....	23
9.4.1    General .....	23
9.4.2    Instance number.....	23
9.4.3    Instance type .....	23
9.4.4    Feature type .....	23
9.4.5    Instance groups .....	24
9.5    Commands .....	24
9.5.1    General .....	24
9.5.2    Device commands .....	24
9.5.3    Instance commands.....	25
9.5.4    Feature commands .....	25
9.6    Event messages .....	25
9.6.1    Response to event messages .....	25
9.6.2    Device power cycle event .....	25
9.6.3    Input notification event .....	25
9.6.4    Event message filter .....	26
9.7    Input signal and input value .....	27
9.7.1    General .....	27
9.7.2    Input resolution.....	27
9.7.3    Getting the input value.....	27
9.7.4    Notification of changes .....	28
9.8    System failure.....	28

9.9	Operating a control device .....	29
9.9.1	Enable/disable the application controller.....	29
9.9.2	Enable/disable event messages.....	29
9.9.3	Quiescent mode .....	29
9.9.4	Modes of operation .....	30
9.10	Memory banks .....	30
9.10.1	General .....	30
9.10.2	Memory map.....	31
9.10.3	Selecting a memory bank location .....	31
9.10.4	Memory bank reading .....	32
9.10.5	Memory bank writing.....	32
9.10.6	Memory bank 0.....	33
9.10.7	Memory bank 1 .....	35
9.10.8	Manufacturer specific memory banks .....	37
9.10.9	Reserved memory banks .....	37
9.11	Reset.....	37
9.11.1	Reset operation .....	37
9.11.2	Reset memory bank operation .....	37
9.12	Power on behaviour .....	37
9.12.1	Power on .....	37
9.12.2	Power cycle notification.....	38
9.13	Priority use .....	38
9.13.1	General .....	38
9.13.2	Priority of input notifications .....	38
9.14	Assigning short addresses .....	39
9.14.1	General .....	39
9.14.2	Random address allocation.....	39
9.14.3	Identification of a device .....	39
9.15	Exception handling .....	40
9.16	Device capabilities and status information .....	40
9.16.1	Device capabilities.....	40
9.16.2	Device status.....	40
9.16.3	Instance status .....	41
9.17	Non-volatile memory .....	41
10	Declaration of variables .....	42
11	Definition of commands .....	43
11.1	General.....	43
11.2	Overview sheets .....	43
11.3	Event messages .....	48
11.3.1	INPUT NOTIFICATION ( <i>device/instance, event</i> ).....	48
11.3.2	POWER NOTIFICATION ( <i>device</i> ) .....	48
11.4	Device control instructions .....	48
11.4.1	General .....	48
11.4.2	IDENTIFY DEVICE .....	48
11.4.3	RESET POWER CYCLE SEEN .....	49
11.5	Device configuration instructions.....	49
11.5.1	General .....	49
11.5.2	RESET .....	49
11.5.3	RESET MEMORY BANK ( <i>DTR0</i> ) .....	49

11.5.4	SET SHORT ADDRESS ( <i>DTR0</i> ) .....	49
11.5.5	ENABLE WRITE MEMORY .....	49
11.5.6	ENABLE APPLICATION CONTROLLER .....	50
11.5.7	DISABLE APPLICATION CONTROLLER .....	50
11.5.8	SET OPERATING MODE ( <i>DTR0</i> ) .....	50
11.5.9	ADD TO DEVICE GROUPS 0-15 ( <i>DTR2:DTR1</i> ) .....	50
11.5.10	ADD TO DEVICE GROUPS 16-31 ( <i>DTR2:DTR1</i> ) .....	50
11.5.11	REMOVE FROM DEVICE GROUPS 0-15 ( <i>DTR2:DTR1</i> ).....	50
11.5.12	REMOVE FROM DEVICE GROUPS 16-31 ( <i>DTR2:DTR1</i> ).....	50
11.5.13	START QUIESCENT MODE .....	50
11.5.14	STOP QUIESCENT MODE .....	50
11.5.15	ENABLE POWER CYCLE NOTIFICATION .....	51
11.5.16	DISABLE POWER CYCLE NOTIFICATION .....	51
11.5.17	SAVE PERSISTENT VARIABLES .....	51
11.6	Device queries .....	51
11.6.1	General .....	51
11.6.2	QUERY DEVICE CAPABILITIES.....	51
11.6.3	QUERY DEVICE STATUS .....	51
11.6.4	QUERY APPLICATION CONTROLLER ERROR .....	52
11.6.5	QUERY INPUT DEVICE ERROR .....	52
11.6.6	QUERY MISSING SHORT ADDRESS.....	52
11.6.7	QUERY VERSION NUMBER.....	52
11.6.8	QUERY CONTENT DTR0 .....	52
11.6.9	QUERY NUMBER OF INSTANCES.....	52
11.6.10	QUERY CONTENT DTR1 .....	52
11.6.11	QUERY CONTENT DTR2 .....	52
11.6.12	QUERY RANDOM ADDRESS (H) .....	53
11.6.13	QUERY RANDOM ADDRESS (M) .....	53
11.6.14	QUERY RANDOM ADDRESS (L).....	53
11.6.15	READ MEMORY LOCATION ( <i>DTR1, DTR0</i> ) .....	53
11.6.16	QUERY APPLICATION CONTROL ENABLED .....	53
11.6.17	QUERY OPERATING MODE .....	53
11.6.18	QUERY MANUFACTURER SPECIFIC MODE .....	53
11.6.19	QUERY QUIESCENT MODE.....	53
11.6.20	QUERY DEVICE GROUPS 0-7 .....	53
11.6.21	QUERY DEVICE GROUPS 8-15 .....	54
11.6.22	QUERY DEVICE GROUPS 16-23 .....	54
11.6.23	QUERY DEVICE GROUPS 24-31 .....	54
11.6.24	QUERY POWER CYCLE NOTIFICATION .....	54
11.6.25	QUERY EXTENDED VERSION NUMBER( <i>DTR0</i> ) .....	54
11.6.26	QUERY RESET STATE .....	54
11.7	Instance control instructions .....	54
11.8	Instance configuration instructions .....	54
11.8.1	General .....	54
11.8.2	ENABLE INSTANCE .....	55
11.8.3	DISABLE INSTANCE .....	55
11.8.4	SET PRIMARY INSTANCE GROUP ( <i>DTR0</i> ) .....	55
11.8.5	SET INSTANCE GROUP 1 ( <i>DTR0</i> ).....	55
11.8.6	SET INSTANCE GROUP 2 ( <i>DTR0</i> ).....	55

11.8.7	SET EVENT SCHEME ( <i>DTR0</i> ).....	55
11.8.8	SET EVENT PRIORITY ( <i>DTR0</i> ).....	56
11.8.9	SET EVENT FILTER ( <i>DTR2, DTR1, DTR0</i> ) .....	56
11.9	Instance queries .....	56
11.9.1	General .....	56
11.9.2	QUERY INSTANCE TYPE .....	56
11.9.3	QUERY RESOLUTION .....	56
11.9.4	QUERY INSTANCE ERROR .....	56
11.9.5	QUERY INSTANCE STATUS .....	56
11.9.6	QUERY INSTANCE ENABLED .....	57
11.9.7	QUERY PRIMARY INSTANCE GROUP .....	57
11.9.8	QUERY INSTANCE GROUP 1.....	57
11.9.9	QUERY INSTANCE GROUP 2.....	57
11.9.10	QUERY EVENT SCHEME.....	57
11.9.11	QUERY INPUT VALUE .....	57
11.9.12	QUERY INPUT VALUE LATCH.....	57
11.9.13	QUERY EVENT PRIORITY .....	57
11.9.14	QUERY FEATURE TYPE .....	58
11.9.15	QUERY NEXT FEATURE TYPE.....	58
11.9.16	QUERY EVENT FILTER 0-7 .....	58
11.9.17	QUERY EVENT FILTER 8-15 .....	58
11.9.18	QUERY EVENT FILTER 16-23.....	58
11.10	Special commands.....	58
11.10.1	General .....	58
11.10.2	TERMINATE .....	58
11.10.3	INITIALISE ( <i>device</i> ) .....	59
11.10.4	RANDOMISE .....	59
11.10.5	COMPARE .....	59
11.10.6	WITHDRAW.....	59
11.10.7	SEARCHADDRH ( <i>data</i> ) .....	60
11.10.8	SEARCHADDRM ( <i>data</i> ) .....	60
11.10.9	SEARCHADDRL ( <i>data</i> ) .....	60
11.10.10	PROGRAM SHORT ADDRESS ( <i>data</i> ) .....	60
11.10.11	VERIFY SHORT ADDRESS ( <i>data</i> ) .....	60
11.10.12	QUERY SHORT ADDRESS .....	61
11.10.13	WRITE MEMORY LOCATION ( <i>DTR1, DTR0, data</i> ) .....	61
11.10.14	WRITE MEMORY LOCATION – NO REPLY ( <i>DTR1, DTR0, data</i> ) .....	61
11.10.15	DTR0 ( <i>data</i> ) .....	61
11.10.16	DTR1 ( <i>data</i> ) .....	62
11.10.17	DTR2 ( <i>data</i> ) .....	62
11.10.18	DIRECT WRITE MEMORY ( <i>DTR1, offset, data</i> ) .....	62
11.10.19	DTR1:DTR0 ( <i>data1, data0</i> ).....	62
11.10.20	DTR2:DTR1 ( <i>data2, data1</i> ).....	62
11.10.21	SEND TESTFRAME ( <i>data</i> ) .....	62
12	Test procedures .....	63
12.1	General notes on test.....	63
12.1.1	General .....	63
12.1.2	Test execution .....	63
12.1.3	Data transmission.....	64

12.1.4	Test setup .....	64
12.1.5	Test output .....	64
12.1.6	Test notation .....	65
12.1.7	Test execution limitations .....	66
12.1.8	Test results .....	66
12.1.9	Exception handling .....	66
12.1.10	Unexpected answer .....	66
12.2	Preamble .....	68
12.2.1	Test preamble .....	68
12.3	Physical operational parameters .....	79
12.3.1	Polarity test .....	79
12.3.2	Maximum and minimum system voltage .....	80
12.3.3	Overshoot protection test .....	80
12.3.4	Current rating test .....	81
12.3.5	Transmitter voltages .....	83
12.3.6	Transmitter rising and falling edges .....	84
12.3.7	Transmitter bit timing .....	86
12.3.8	Transmitter frame timing .....	88
12.3.9	Receiver start-up behavior .....	89
12.3.10	Receiver threshold .....	90
12.3.11	Receiver bit timing .....	91
12.3.12	Extended receiver bit timing .....	95
12.3.13	Receiver forward frame violation .....	97
12.3.14	Receiver settling timing .....	97
12.3.15	Receiver frame timing FF-FF send twice .....	98
12.3.16	Transmitter collision avoidance by priority .....	100
12.3.17	Transmitter collision detection for truncated idle phase .....	101
12.3.18	Transmitter collision detection for extended active phase .....	104
12.4	Device configuration instructions .....	107
12.4.1	RESET deviceGroups .....	107
12.4.2	RESET quiescentMode .....	108
12.4.3	RESET instance groups .....	109
12.4.4	RESET event filter .....	110
12.4.5	RESET event scheme .....	111
12.4.6	RESET: timeout / command in-between .....	112
12.4.7	Send twice timeout (device) .....	114
12.4.8	Send twice timeout (instance) .....	117
12.4.9	Commands in-between (device) .....	119
12.4.10	Commands in-between (instance) .....	122
12.4.11	SAVE PERSISTENT VARIABLES .....	125
12.4.12	SET OPERATING MODE .....	125
12.4.13	Device Disable/Enable Application Controller .....	126
12.4.14	Multi Master Control Device PING .....	127
12.4.15	Quiescent Mode .....	128
12.4.16	Device power cycle notification .....	129
12.4.17	SET SHORT ADDRESS .....	130
12.4.18	Reset/Power-on values (device) .....	131
12.4.19	Reset/Power-on values (instance) .....	133
12.4.20	DTR0 / DTR1 / DTR2 .....	134

12.4.21	DTR1:DTR0 and DTR2:DTR1 .....	135
12.4.22	Device Groups.....	136
12.5	Device queries .....	137
12.5.1	Device query capabilities .....	137
12.5.2	QUERY VERSION NUMBER.....	137
12.5.3	Device power cycle seen .....	138
12.5.4	Input device error .....	138
12.6	Device Memory banks.....	139
12.6.1	READ MEMORY LOCATION on Memory Bank 0.....	139
12.6.2	READ MEMORY LOCATION on Memory Bank 1.....	144
12.6.3	READ MEMORY LOCATION on other Memory Banks.....	146
12.6.4	Memory bank writing.....	148
12.6.5	ENABLE WRITE MEMORY: writeEnableState.....	153
12.6.6	ENABLE WRITE MEMORY: timeout / command in-between.....	155
12.6.7	RESET MEMORY BANK: timeout / command in-between .....	156
12.6.8	RESET MEMORY BANK.....	159
12.7	Device Special commands .....	160
12.7.1	INITIALISE – timer.....	160
12.7.2	TERMINATE .....	161
12.7.3	INITIALISE - device addressing .....	162
12.7.4	RANDOMISE .....	163
12.7.5	COMPARE .....	163
12.7.6	WITHDRAW.....	165
12.7.7	SEARCHADDRH / SEARCHADDRM / SEARCHADDRL .....	166
12.7.8	PROGRAM SHORT ADDRESS .....	167
12.7.9	VERIFY SHORT ADDRESS .....	169
12.7.10	QUERY SHORT ADDRESS .....	170
12.7.11	IDENTIFY DEVICE .....	172
12.8	Logical unit cross contamination .....	174
12.8.1	DTR0 .....	174
12.8.2	NVM variables .....	174
12.8.3	Random address generation .....	175
12.8.4	Addressing 1 .....	176
12.8.5	Addressing 2 .....	177
12.8.6	Addressing 3 .....	179
12.9	Instance addressing .....	180
12.9.1	Instance Type Addressing .....	180
12.9.2	Instance Primary Group .....	181
12.9.3	Instance Group 2 .....	182
12.9.4	Instance Group 1 .....	184
12.9.5	Instance Group Combinations .....	185
12.9.6	Multiple Instances Answer .....	187
12.10	Instance configuration instructions .....	188
12.10.1	Instance Enable/Disable .....	188
12.10.2	Event Scheme .....	190
12.10.3	Input Resolution & Input Value .....	195
12.10.4	Event Filter .....	195
12.11	Instance queries .....	196
12.11.1	Instance Number and Types .....	196

12.11.2	Instance Status.....	197
12.11.3	Instance Error.....	197
12.12	Instance cross contamination.....	198
12.12.1	Instance Event Priority.....	198
12.13	Reserved Commands.....	199
12.13.1	Reserved standard device commands.....	199
12.13.2	Reserved instance commands (instance type 0) .....	200
12.13.3	Reserved special commands .....	200
12.14	General subsequences .....	201
12.14.1	Reset Device .....	201
12.14.2	EnableApplicationControllerAndAllInstances.....	202
12.14.3	DisableApplicationControllerAndAllInstances .....	202
12.14.4	Has ApplicationController .....	202
12.14.5	GetVersionNumber .....	203
12.14.6	AddDeviceGroups.....	203
12.14.7	RemoveDeviceGroups .....	203
12.14.8	ClearAllDeviceGroups.....	204
12.14.9	CheckDeviceGroups .....	204
12.14.10	GetDeviceGroups .....	205
12.14.11	PowerCycle .....	205
12.14.12	PowerCycleAndWaitForBusPower .....	205
12.14.13	PowerCycleAndWaitForDecoder .....	206
12.14.14	SetupTestFrame .....	206
12.14.15	GetNumberOfInstances .....	207
12.14.16	GetEventFilter .....	207
12.14.17	SetEventFilter.....	207
12.14.18	GetNumberOfLogicalUnits .....	207
12.14.19	GetIndexOfLogicalUnit.....	207
12.14.20	GetRandomAddress.....	208
12.14.21	GetLimitedRandomAddress .....	208
12.14.22	SetSearchAddress .....	208
12.14.23	SetShortAddress .....	209
12.14.24	ReadMemBankMultibyteLocation .....	209
12.14.25	FindImplementedMemoryBank.....	210
12.14.26	FindAllImplementedMemoryBanks .....	210
12.14.27	ShortAddress.....	211
12.14.28	GroupAddress .....	211
12.14.29	Broadcast .....	211
12.14.30	BroadcastUnaddressed.....	211
12.14.31	InstanceNumber .....	211
12.14.32	InstanceGroup .....	212
12.14.33	InstanceType .....	212
12.14.34	InstanceBroadcast .....	212
12.14.35	FeatureOfInstanceNumber.....	212
12.14.36	FeatureOfInstanceGroup .....	213
12.14.37	FeatureOfInstanceType .....	213
12.14.38	FeatureOfInstanceBroadcast .....	213
12.14.39	FeatureOfDevice .....	213
12.14.40	FeatureOfDeviceWithGroupAddress .....	214

12.14.41 FeatureOfDeviceWithBroadcast .....	214
Bibliography.....	215
Figure 1 - IEC 62386 graphical overview.....	13
Figure 2 – Current rating test .....	82
Table 1 – 24-bit command frame encoding.....	19
Table 2 – Instance byte in a command frame .....	19
Table 3 – 24-bit event message frame encoding .....	20
Table 4 – Instance types .....	23
Table 5 – Feature types .....	23
Table 6 – Instance group variables .....	24
Table 7 – Device address information in power cycle event .....	25
Table 8 – Event addressing schemes.....	26
Table 9 – Signal level (~50%) versus resolution and input value .....	27
Table 10 – Example querying sequence to read a 4-byte input value .....	28
Table 11 – Basic memory map of memory banks .....	31
Table 12 – Memory map of memory bank 0.....	34
Table 13 – Memory map of memory bank 1.....	36
Table 14 – Control device capabilities.....	40
Table 15 – Control device status.....	40
Table 16 – Instance status.....	41
Table 17 – Declaration of device variables.....	42
Table 18 – Declaration of instance variables.....	43
Table 19 – Instance event messages .....	43
Table 20 – Device event messages.....	43
Table 21 – Standard commands.....	44
Table 22 – Special commands (implemented by both application controller and input device).....	47
Table 23 – Device addressing with “INITIALISE ( <i>device</i> )” .....	59
Table 24 – Unexpected outcome.....	67
Table 25 – Parameters for test sequence Check Factory Default 103.....	74
Table 26 – Parameters for test sequence CheckFactoryDefault103PerLogicalUnit .....	77
Table 27 – Parameters for test sequence Transmitter bit timing .....	79
Table 28 – Parameters for test sequence Maximum and minimum system voltage .....	80
Table 29 – Parameters for test sequence Transmitter voltages .....	84
Table 30 – Parameters for test sequence Transmitter rising and falling edges .....	85
Table 31 – Parameters for test sequence Transmitter bit timing .....	88
Table 32 – Parameters for test sequence Receiver frame timing .....	89
Table 33 – Parameters for test sequence Receiver start-up behavior.....	90
Table 34 – Parameters for test sequence Receiver bit timing .....	92
Table 35 – Parameters for test sequence extended receiver bit timing .....	96
Table 36 – Parameters for test sequence Receiver frame violation and recovering after frame size violation .....	97

Table 37 – Parameters for test sequence Receiver frame timing .....	98
Table 38 – Parameters for test sequence transmitter collision avoidance by priority .....	101
Table 39 – Parameters for test sequence transmitter collision detection for truncated idle phase .....	104
Table 40 – Parameters for test sequence transmitter collision detection for extended active phase .....	107
Table 41 – Parameters for test sequence RESET instance groups .....	110
Table 42 – Parameters for test sequence Send twice timeout (device) .....	116
Table 43 – Parameters for test sequence Send twice timeout (instance) .....	118
Table 44 – Parameters for test sequence Commands in-between (device) .....	121
Table 45 – Parameters for test sequence Commands in-between .....	124
Table 46 – Parameters for test sequence SET SHORT ADDRESS .....	131
Table 47 – Parameters for test sequence Reset/Power-on values (device) .....	132
Table 48 – Parameters for test sequence Reset/Power-on values (instance) .....	134
Table 49 – Parameters for test sequence DTR0 / DTR1 / DTR2 .....	134
Table 50 – Parameters for test sequence DTR1:DTR0 and DTR2:DTR1 .....	136
Table 51 – Parameters for test sequence READ MEMORY LOCATION on Memory Bank 0 .....	143
Table 52 – Parameters for test sequence READ MEMORY LOCATION on Memory Bank 1 .....	146
Table 53 – Parameters for test sequence Memory bank writing .....	151
Table 54 – Parameters for test sequence ENABLE WRITE MEMORY: writeEnableState .....	154
Table 55 – Parameters for test sequence ENABLE WRITE MEMORY: timeout / command in-between .....	156
Table 56 – Parameters for test sequence RESET MEMORY BANK: timeout / command in-between .....	159
Table 57 – Parameters for test sequence RESET MEMORY BANK .....	160
Table 58 – Parameters for test sequence INITIALISE - device addressing .....	162
Table 59 – Parameters for test sequence COMPARE .....	164
Table 60 – Parameters for test sequence WITHDRAW .....	166
Table 61 – Parameters for test sequence PROGRAM SHORT ADDRESS .....	168
Table 62 – Parameters for test sequence VERIFY SHORT ADDRESS .....	170
Table 63 – Parameters for test sequence QUERY SHORT ADDRESS .....	171
Table 64 – Parameters for test sequence IDENTIFY DEVICE .....	173
Table 65 – Parameters for test sequence Addressing 2 .....	179
Table 66 – Parameters for test sequence Reserved commands: standard device commands .....	199
Table 67 – Parameters for test sequence Reserved instance commands (instance type 0) .....	200
Table 68 – Parameters for test sequence Reserved special commands .....	201

## INTRODUCTION


IEC 62386 contains several parts, referred to as series. The 1xx series includes the basic specifications. Part 101 contains general requirements for system components, Part 102 extends this information with general requirements for control gear and Part 103 extends it further with general requirements for control devices.

The 2xx parts extend the general requirements for control gear with lamp specific extensions (mainly for backward compatibility with Edition 1 of IEC 62386) and with control gear specific features.

The 3xx parts extend the general requirements for control devices with input device specific extensions describing the instance types as well as some common features that can be combined with multiple instance types.

This first edition of IEC 62386-103 is published in conjunction with IEC 62386-101:2014, IEC 62386-102:2014 and with the various parts that make up the IEC 62386-2xx series for control gear, together with the various parts that make up the IEC 62386-3xx series of particular requirements for control devices. The division into separately published parts provides for ease of future amendments and revisions. Additional requirements will be added as and when a need for them is recognised.

The setup of the standard is graphically represented in **Error! Reference source not found.** below



**Figure 1 - IEC 62386 graphical overview**

When this part of IEC 62386 refers to any of the clauses of the other two parts of the IEC 62386-1xx series, the extent to which such a clause is applicable and the order in which the tests are to be performed are specified. The other parts also include additional requirements, as necessary.

All numbers used in this International Standard are decimal numbers unless otherwise noted.

Hexadecimal numbers are given in the format 0xVV, where VV is the value. Binary numbers are given in the format XXXXXXXXb or in the format XXXX XXXX, where X is 0 or 1, "x" in binary numbers means "don't care".

The following typographic expressions are used:

Variables: *variableName* or *variableName[3:0]*, giving only bits 3 to 0 of *variableName*.

Range of values: [lowest, highest]

Command: “COMMAND NAME”