

ICS 13.040.30

English Version

**Workplace exposure - Guide for the use of direct-reading
instruments for aerosol monitoring - Part 2: Evaluation of
airborne particle concentrations using Optical Particle Counters**

Exposition au poste de travail - Guide d'utilisation des
instruments à lecture directe pour la surveillance des
aérosols - Partie 2 : Evaluation des concentrations de
particules en suspension dans l'air à l'aide de compteurs
optiques de particules

Exposition am Arbeitsplatz - Leitfaden für die Anwendung
direkt anzeigender Geräte zur Überwachung von Aerosolen
- Teil 2: Ermittlung der Konzentration Luft getragener
Partikel mit optischen Partikelzählern

This Technical Report was approved by CEN on 13 March 2010. It has been drawn up by the Technical Committee CEN/TC 137.

CEN members are the national standards bodies of Austria, Belgium, Bulgaria, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland and United Kingdom.



EUROPEAN COMMITTEE FOR STANDARDIZATION
COMITÉ EUROPÉEN DE NORMALISATION
EUROPÄISCHES KOMITEE FÜR NORMUNG

Management Centre: Avenue Marnix 17, B-1000 Brussels

Contents

Page

Foreword.....	4
Introduction	5
1 Scope	6
2 Principles of the method	7
2.1 Light scattering	7
2.2 Working principle.....	7
3 OPC performance characteristics	8
4 Number and mass concentrations	8
5 Mass concentrations of thoracic and respirable aerosol fractions.....	9
6 OPC use	10
6.1 General.....	10
6.2 Airflow adjustment.....	11
6.3 Calibration of particle count response.....	11
6.4 Calibration of particle diameter response.....	11
6.5 Mass concentration response	11
7 Fundamental and practical limitations	12
7.1 Refraction index and particle density.....	12
7.2 Forward scattering instruments.....	12
7.3 Limitation in particle size.....	12
7.4 Coincidence error and concentration limitation.....	12
7.5 Aerosols from several sources	12
8 Instrumentation characteristics	13
8.1 Aspiration system.....	13
8.2 Integrated collection filter.....	13
8.3 Sampling head	13
8.4 Optical cell.....	13
8.5 Electronics.....	13
8.6 Case of laser instruments	13
9 Aerosol measurement by OPC	13
9.1 Operating procedure	13
9.2 Cartography of workplace	14
9.3 Working shift monitoring	14
9.4 Sampling record.....	14
9.5 Cleaning and maintenance	14
Annex A (informative) Evaluation of an OPC as an instrument for thoracic and respirable mass concentrations	15
A.1 Introduction to workplace evaluation.....	15
A.2 Procedure for field comparison of the OPC with the reference sampler.....	15
A.2.1 General.....	15
A.2.2 Comparison of a static OPC with a static reference sampler	16
A.2.3 Comparison of mass concentrations for the respirable or thoracic aerosol fractions calculated from OPC data with a reference sampler.....	16
A.3 Calculation methods	16
A.3.1 General.....	16
A.3.2 Estimation of the correction coefficient.....	16
A.3.3 Exclusion of outliers	17

A.3.4	Residual uncertainty after transformation by the correction function	17
A.3.5	Equivalence.....	17
A.4	Periodic validation.....	17
A.5	Documentation	18
A.5.1	General	18
A.5.2	Description of the OPC and the reference sampler	18
A.5.3	Critical review of sampling process	18
A.5.4	Circumstances of field comparison	18
A.5.5	Details of experimental design	18
A.5.6	Data analysis.....	18
A.5.7	Equivalence.....	19
A.6	Nomenclature.....	19
Annex B (informative)	Example for the determination of the correction coefficient for an OPC	20
Bibliography	23

This document is a preview generated by EVS

Foreword

This document (CEN/TR 16013-2:2010) has been prepared by Technical Committee CEN/TC 137 "Assessment of workplace exposure to chemical and biological agents", the secretariat of which is held by DIN.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. CEN [and/or CENELEC] shall not be held responsible for identifying any or all such patent rights.

CEN/TR 16013, *Workplace exposure — Guide for the use of direct-reading instruments for aerosol monitoring*, consists of the following parts:

- *Part 1: Choice of monitor for specific applications*
- *Part 2: Evaluation of airborne particle concentrations using Optical Particle Counters*
- *Part 3: Evaluation of airborne particle concentrations using photometers (in preparation)*

Introduction

Optical Particle Counters (OPC) count airborne particles and are therefore suitable for measuring concentrations expressed in number of particles per unit volume of air. Counting-based measurement of mass concentration and particle size estimation is indirect: a number of assumptions and approximations are made to access the information sought. Nevertheless, optical particle counters can be used to evaluate the efficiency of preventive actions and to monitor the spatial distribution and/or the temporal evolution of an aerosol. In occupational hygiene, no standard recommends workers' exposure assessment using optical particle counters. These instruments should instead be considered as permitting a complementary approach to the conventional filter-based gravimetric method. A confirmation of OPC mass concentration by a conventional sampling method with a calibrated instrument is recommended when comparing concentration measurements with legal limit values.

An OPC method allows assessment of working place aerosol conditions including:

- almost instantaneous evaluation of particle concentration and size distribution;
- estimating concentration variations and mean concentration of aerosol particles during a working shift period;
- sampling to constitute a particle sample for further analysis (when equipped with terminal filter).

1 Scope

This Technical Report describes the principle underlying evaluation of one or more health related aerosol fractions using an optical particle counter and details its limits and possibilities in the field of occupational hygiene.

The method complements conventional long-term aerosol particle sampling and offers possibilities of:

- instantaneous (direct reading) measurement;
- time-related monitoring;
- investigation of space-related aerosol evolution (mapping);
- assessment of particle size distribution.

The method enables e.g.:

- detection and relative quantification of concentration peaks due to specific operations (bagging, sanding, etc.);
- identification of most exposed workers with a view to more detailed studies of risks and prevention measures to be applied;
- detection of dust emission sources and their relative magnitudes.

Basically, OPCs count airborne particles and are therefore suitable for measuring concentrations expressed in number of particles per unit volume of air. The applicability of the method is limited by the particle size and concentration ranges of OPC instruments, usually approximately $10^{-1} \mu\text{m}$ to $10^1 \mu\text{m}$ and 10^0 particles/cm³ to 10^3 particles/cm³, respectively.

Depending on specific conditions, the OPC method allows filter collection of an aerosol fraction, in the best case close to a health-related fraction (see EN 481), provided the OPC has the relevant sampling efficiency over its optical particle size range. If this is not the case, at least a sufficient aspiration efficiency is required to cover the size range of particles which can be detected and measured by the OPC optical system.

Converting count-based particle number concentrations into mass concentrations based on estimated particle size is indirect and therefore the accuracy of the conversion is limited by several simplifying assumptions:

- identical optical parameters for both the calibration aerosol and the measured workplace aerosol;
- all counted particles of the workplace aerosol are spherical with a geometric diameter equal to the determined optical diameter and with identical density;
- the aspiration and transmission efficiencies of the OPC are known or estimated from engineering models.

Therefore confirmation of the estimated mass concentrations from OPC particle size distributions by a conventional sampling method is necessary (see [3]). The estimated mass concentrations from OPC data are only indicative and cannot be used for a direct comparison with a legally enforced occupational exposure limit.

2 Principles of the method

2.1 Light scattering

An aerosol particle scatters light energy through the effects of reflection, refraction absorption, and diffraction. The amount of energy scattered can be calculated by applying Mie's theory (see [8]), which can be summarised by the following simplified equation for a non-polarised monochromatic incident light beam and a spherical particle:

$$I = I_0 \frac{1}{8\pi} \frac{\lambda^2}{r^2} [i_1(\alpha, n, \theta) + i_2(\alpha, n, \theta)] \quad (1)$$

where

- I is the intensity of light scattered at angle θ , per unit cross-sectional area, in watts per square metre;
- I_0 is the intensity of the incident beam, per unit cross-sectional area, in watts per square metre;
- α is the particle size parameter, where $\alpha = \pi \times D / \lambda$ and D is the spherical particle diameter, in micrometres;
- n is the particle complex refraction index;
- λ is the wavelength of incident light, in micrometres;
- r is the distance from the centre of the scattering particle to the point where the intensity, I , is measured, in micrometres;
- θ is the scattering angle;
- i_1, i_2 are Mie intensity functions.

The particle diameter D can be deduced from Equation (1) by measuring the intensity of light scattered, when the particle optical parameters and the incident light beam characteristics are known.

2.2 Working principle

OPCs are closed optical cell instruments featuring an aerosol aspiration system. They are characterised by their very low optical measuring volume (of the order of 1 mm³) and by a flow rate often of the order of 1 l/min (see [9]). This allows particles to be drawn individually into the sensing zone and recording of the light scattered by each particle. Discrete pulses are counted and their size measured.

The aerosol to be investigated is aspirated through the instrument sampling probe by a constant flow pump. Particles pass one by one into the optical cell, where each particle is illuminated by a focused light beam of specified characteristics and scatters this light according to its properties (complex refraction index, size, shape).

Particles move perpendicularly to the plane formed by the focused light incident beam and the scattered light reception beam. Optical parts are swept by filtered air to prevent any particle deposition inside the optical cell.

The scattered light is focused onto a photo detector and recorded as a pulse. From the pulse size, the particle size is inferred assuming spherical particles. A quantity of signals during predefined integration time can be converted into mass concentration, usually after calibration using the investigated aerosol.