Workplace exposure - Measurement of dustiness of bulk materials that contain or release respirable NOAA or other respirable particles - Part 5: Vortex shaker method



### EESTI STANDARDI EESSÕNA

### NATIONAL FOREWORD

	This Estonian standard EVS-EN 17199-5:2019 consists of the English text of the European standard EN 17199-5:2019.
Standard on jõustunud sellekohase teate avaldamisega EVS Teatajas	This standard has been endorsed with a notification published in the official bulletin of the Estonian Centre for Standardisation.
Euroopa standardimisorganisatsioonid on teinud Euroopa standardi rahvuslikele liikmetele kättesaadavaks 27.03.2019.	Date of Availability of the European standard is 27.03.2019.
Standard on kättesaadav Eesti Standardikeskusest.	The standard is available from the Estonian Centre for Standardisation.

Tagasisidet standardi sisu kohta on võimalik edastada, kasutades EVS-i veebilehel asuvat tagasiside vormi või saates e-kirja meiliaadressile <u>standardiosakond@evs.ee</u>.

### ICS 13.040.30

Standardite reprodutseerimise ja levitamise õigus kuulub Eesti Standardikeskusele

Andmete paljundamine, taastekitamine, kopeerimine, salvestamine elektroonsesse süsteemi või edastamine ükskõik millises vormis või millisel teel ilma Eesti Standardikeskuse kirjaliku loata on keelatud.

Kui Teil on küsimusi standardite autorikaitse kohta, võtke palun ühendust Eesti Standardikeskusega: Koduleht <a href="www.evs.ee">www.evs.ee</a>; telefon 605 5050; e-post <a href="mailto:info@evs.ee">info@evs.ee</a>

The right to reproduce and distribute standards belongs to the Estonian Centre for Standardisation

No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying, without a written permission from the Estonian Centre for Standardisation.

If you have any questions about copyright, please contact Estonian Centre for Standardisation:

Homepage www.evs.ee; phone +372 605 5050; e-mail info@evs.ee

# EUROPEAN STANDARD

# NORME EUROPÉENNE

# **EUROPÄISCHE NORM**

March 2019

EN 17199-5

ICS 13.040.30

### **English Version**

## Workplace exposure - Measurement of dustiness of bulk materials that contain or release respirable NOAA or other respirable particles - Part 5: Vortex shaker method

Exposition sur les lieux de travail - Mesurage du pouvoir de resuspension des matériaux en vrac contenant ou émettant des nano-objets et leurs agrégats et agglomérats (NOAA) ou autres particules en fraction alvéolaire - Partie 5: Méthode impliquant l'utilisation d'un agitateur vortex

Exposition am Arbeitsplatz - Messung des Staubungsverhaltens von Schüttgütern, die Nanoobjekte oder Submikrometerpartikel enthalten oder freisetzen - Teil 5: Verfahren mit Vortex-Schüttler

This European Standard was approved by CEN on 8 February 2019.

CEN members are bound to comply with the CEN/CENELEC Internal Regulations which stipulate the conditions for giving this European Standard the status of a national standard without any alteration. Up-to-date lists and bibliographical references concerning such national standards may be obtained on application to the CEN-CENELEC Management Centre or to any CEN member.

This European Standard exists in three official versions (English, French, German). A version in any other language made by translation under the responsibility of a CEN member into its own language and notified to the CEN-CENELEC Management Centre has the same status as the official versions.

CEN members are the national standards bodies of Austria, Belgium, Bulgaria, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, Former Yugoslav Republic of Macedonia, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Serbia, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turkey and United Kingdom.



EUROPEAN COMMITTEE FOR STANDARDIZATION COMITÉ EUROPÉEN DE NORMALISATION EUROPÄISCHES KOMITEE FÜR NORMUNG

CEN-CENELEC Management Centre: Rue de la Science 23, B-1040 Brussels

Cont	ents	Page
Furan	ean foreword	1
-	uction	
1	Scope	
2	Normative references	7
3	Terms and definitions	7
4	Symbols and abbreviations	8
5	Principle	
6	Equipment	
6.1	General	
6.2	Test apparatus	
6.2.1	Vortex shaker apparatus	
6.2.2	Cylindrical container	
6.2.3	Humidification system of incoming and dilution air	
6.2.4	Sampling line for the measurement of the respirable dustiness mass fraction	
6.2.5	Sampling line for other measurements	
6.2.6	Conductive flexible tubing, carbon impregnated	
6.2.7	Respirable cyclone, made of stainless steel	19
6.2.8	Air sampling cassette	
6.2.9	Condensation particle counter (CPC), with alcohol as working fluid	
	Time- and size-resolving aerosol instrument	
	Aerosol sampler for analytical electron microscopy analysis	
	Analytical balance, capable of weighing to a resolution of 10 $\mu g$	
6.2.13	Microbalance, capable of weighing to a resolution of 1 $\mu g$	21
	Filters for gravimetric analysis	
6.2.15	Micro-centrifuge tubes	
7	Requirements	21
7.1	General	
7.2	Engineering control measures	
7.3	Conditioning of the test material	
7.3.1	General	
7.3.2	Specified conditions	22
7.3.3	As-received conditions	
7.4	Conditioning of the test equipment	
8	Preparation	
8.1	Test sample	
8.2	Moisture content of the test material	
8.3	Bulk density of the test material	
8.4	Preparation of test apparatus	
8.5	Aerosol instruments and aerosol samplers	23
9	Test procedure	23
10	Evaluation of data	26
10.1	Respirable dustiness mass fraction	

10.2.1 General	10.2	Number-based dustiness index, number-based emission rate and modal aerodynamic equivalent diameters of the particle size distribution	26
10.2.4 Modal aerodynamic equivalent diameters of the number-based particle size distribution		General	26
10.2.4 Modal aerodynamic equivalent diameters of the number-based particle size distribution			
10.3 Morphological and chemical characterization of the particles		Modal aerodynamic equivalent diameters of the number-based particle size	
Annex A (informative) Pictures illustrating some of the equipment of the method	10.3		
Annex B (informative) Examples of TEM images obtained with the vortex shaker method	11	Test report	29
Annex B (informative) Examples of TEM images obtained with the vortex shaker method	Annex	A (informative) Pictures illustrating some of the equipment of the method	30
Bibliography 37			
On the design of	Annex	C (informative) Motivation for development of the vortex shaker method	36
Protion of the other states of the other state		anauhu.	
3			
			3

## **European foreword**

This document (EN 17199-5:2019) has been prepared by Technical Committee CEN/TC 137 "Assessment of workplace exposure to chemical and biological agents", the secretariat of which is held by DIN.

This European Standard shall be given the status of a national standard, either by publication of an identical text or by endorsement, at the latest by September 2019 and conflicting national standards shall be withdrawn at the latest by September 2019.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. CEN shall not be held responsible for identifying any or all such patent rights.

This document has been prepared under a mandate given to CEN by the European Commission and the European Free Trade Association.

According to the CEN-CENELEC Internal Regulations, the national standards organizations of the following countries are bound to implement this European Standard: Austria, Belgium, Bulgaria, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, Former Yugoslav Republic of Macedonia, rela.
a, Serbia, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Serbia, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turkey and the United Kingdom.

### Introduction

Dustiness measurement and characterization provide users (e.g. manufacturers, producers, occupational hygienists and workers) with information on the potential for dust emissions when bulk material is handled or processed in workplaces. They provide the manufactures of bulk materials containing NOAA with information that can help to improve their products and reduce their dustiness. It allows the users of the bulk materials containing NOAA to assess the controls and precautions required for handling and working with the material and the effects of pre-treatments (e.g. modify surface properties or chemistry). It also allows the users to select less dusty products, if available. The particle size distribution of the aerosol and the morphology and chemical composition of its particles can be used by occupational hygienists, scientists and regulators to further characterize the aerosol in terms of particle size distribution and chemical composition and to thus aid users to evaluate and control the health risk of airborne dust.

This document gives details on the design and operation of the vortex shaker test method that measures the dustiness of bulk materials that contain or release respirable NOAA or other respirable particles in terms of dustiness indices or emission rates. Dustiness indices as well as emission rates can be determined number- or mass-based. In addition the test method characterizes the released aerosol by measuring the particle size distribution using direct-reading aerosol instruments and collects samples for off-line analysis (as required) for their morphology and their chemical composition.

The vortex shaker method is useful for addressing the ability of bulk materials including nanomaterials (in powder form), to release airborne particles (aerosol) during agitation, the so-called dustiness.

The vortex shaker method provides a simulation of operation or processes where the agitation mechanism delivering energy to the powder to release airborne particles is the vibration or shaking mechanism. Vibration and shaking are mechanisms that are often found in industry, either voluntarily or involuntarily. Many surfaces receiving powders are vibrating or shaking, as for example during powder transportation by belt feeder or vibrating conveyor. Moreover, by providing an energetic aerosolization, the vortex shaker method provides even a simulation of the worst-case scenario in a workplace, as for example the (non-recommended) practice of cleaning contaminated worker coveralls and dry work surfaces with compressed air.

The vortex shaker method presented here differs from the rotating drum, the continuous drop and the small rotating drum methods presented in EN 17199-2 [1], EN 17199-3 [2] and EN 17199-4 [3] respectively. The rotating drum and small rotating drum methods perform, both, repeated agitation of the same sample nanomaterial while the continuous drop method simulates continuous feed of a nanomaterial. The method described in this document, in turn, provides an agitation to a small test sample of powder.

This document was developed based on the results of pre-normative research [4]. This project investigated the dustiness of ten bulk materials (including nine bulk nanomaterials) with the intention to test as wide a range of bulk materials as possible in terms of magnitude of dustiness, chemical composition and primary particle size distribution as indicated by a large range in specific surface area.

### 1 Scope

This document describes the methodology for measuring and characterizing the dustiness of bulk materials that contain or release respirable NOAA or other respirable particles, under standard and reproducible conditions and specifies for that purpose the vortex shaker method.

This document specifies the selection of instruments and devices and the procedures for calculating and presenting the results. It also gives guidelines on the evaluation and reporting of the data.

The methodology described in this document enables

- a) the measurement of the respirable dustiness mass fraction,
- b) the measurement of the number-based dustiness index of respirable particles in the particle size range from about 10 nm to about  $1 \mu \text{m}$ ,
- c) the measurement of the number-based emission rate of respirable particles in the particle size range from about 10 nm to about  $1 \mu m$ ,
- d) the measurement of the number-based particle size distribution of the released respirable aerosol in the particle size range from about 10 nm to  $10 \text{ }\mu\text{m}$ ,
- e) the collection of released airborne particles in the respirable fraction for subsequent observations and analysis by electron microscopy.

This document is applicable to the testing of a wide range of bulk materials including nanomaterials in powder form.

NOTE 1 With slightly different configurations of the method specified in this document, dustiness of a series of carbon nanotubes has been investigated ([5] to [10]). On the basis of this published work, it can be assumed that the vortex shaker method is also applicable to nanofibres and nanoplates.

This document is not applicable to millimetre-sized granules or pellets containing nano-objects in either unbound, bound uncoated and coated forms.

- NOTE 2 The restrictions with regard to the application of the vortex shaker method on different kinds of nanomaterials result from the configuration of the vortex shaker apparatus as well as from the small size of the test sample required. Eventually, if future work will be able to provide accurate and repeatable data demonstrating that an extension of the method applicability is possible, the intention is to revise this document and to introduce further cases of method application.
- NOTE 3 As observed in the pre-normative research project [4], the vortex shaker method specified in this document provides a more energetic aerosolization than the rotating drum, the continuous drop and the small rotating drum methods specified in EN 17199-2 [1], EN 17199-3 [2] and EN 17199-4 [3], respectively. The vortex shaker method can better simulate high energy dust dispersion operations or processes where vibration or shaking is applied or even describe a worst case scenario in a workplace, including the (non-recommended) practice of cleaning contaminated worker coveralls and dry work surfaces with compressed air.
- NOTE 4 Currently no classification scheme in terms of dustiness indices or emission rates has been established according to the vortex shaker method. Eventually, when a large number of measurement data has been obtained, the intention is to revise the document and to introduce such a classification scheme, if applicable.

### 2 Normative references

The following documents are referred to in the text in such a way that some or all of their content constitutes requirements of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

CEN ISO/TS 80004-2, Nanotechnologies - Vocabulary - Part 2: Nano-objects (ISO/TS 80004-2)

EN 481, Workplace atmospheres - Size fraction definitions for measurement of airborne particles

EN 1540, Workplace exposure - Terminology

EN 13205-2, Workplace exposure - Assessment of sampler performance for measurement of airborne particle concentrations - Part 2: Laboratory performance test based on determination of sampling efficiency

EN 15051-1, Workplace exposure - Measurement of the dustiness of bulk materials - Part 1: Requirements and choice of test methods

EN 17199-1, Workplace exposure - Measurement of dustiness of bulk materials that contain or release respirable NOAA or other respirable particles - Part 1: Requirements and choice of test methods

EN 16897, Workplace exposure - Characterization of ultrafine aerosols/nanoaerosols - Determination of number concentration using condensation particle counters

ISO 15767, Workplace atmospheres - Controlling and characterizing uncertainty in weighing collected aerosols

ISO 27891, Aerosol particle number concentration - Calibration of condensation particle counters

#### 3 Terms and definitions

For the purposes of this document, the terms and definitions given in EN 1540, EN 15051-1, CEN ISO/TS 80004-2 and EN 17199-1 apply.

ISO and IEC maintain terminological databases for use in standardization at the following addresses:

- IEC Electropedia: available at <a href="http://www.electropedia.org/">http://www.electropedia.org/</a>
- ISO Online browsing platform: available at <a href="http://www.iso.org/obp">http://www.iso.org/obp</a>