TECHNICAL REPORT

ISO TR 9824-1

First edition 1990-05-15

Measurement of free surface flow in closed conduits -

Part 1: Methods

Mesurage du débit des écoulements à surface dénoyée dans les conduites fermées -

Partie 1: Méthodes



Reference number ISO/TR 9824-1:1990(E)

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

The main task of technical committees is to prepare International Standards, but in exceptional circumstances a technical committee may propose the publication of a Technical Report of one of the following types:

- type 1, when the required support cannot be obtained for the publication of an International Standard, despite repeated efforts;
- type 2, when the subject is still under technical development or where for any other reason there is the future but not immediate possibility of an agreement on an International Standard;
- type 3, when a technical committee has collected data of a different kind from that which is normally published as an International Standard ("state of the art", for example).

Technical Reports of types 1 and 2 are subject to review within three years of publication, to decide whether they can be transformed into International Standards. Technical Reports of type 3 do not necessarily have to be reviewed until the data they provide are considered to be no longer valid or useful.

ISO/TR 9824-1, which is a Technical Report of type 2, was prepared by Technical Committee ISO/TC 113, *Measurement of liquid flow in open channels*.

ISO/TR 9824 consists of the following parts, under the general title Measurement of free surface flow in closed conduits : 00 02 17 . (

- Part 1: Methods
- Part 2: Equipment

© ISO 1990

All rights reserved. No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from the publisher.

International Organization for Standardization

Case Postale 56 • CH-1211 Genève 20 • Switzerland Printed in Switzerland

ii

this document is a preview generated by the

Introduction

The measurement of fluid flow and level in partially filled closed conduits presents particularly difficult problems and is not fully documented. This part of ISO/TR 9824 has been prepared therefore to give guidance to users on the existing methods employed and on recent developments in this field.

The measurement of free surface flow in closed conduits is analogous to normal gauging in open channels, and thus open channel gauging techniques may be applied to free surface flows in closed conduits. Closed conduits may be classified as

- a) foul (sanitary), where only domestic and industrial waste are conveyed in the conduit,
- b) storm, where, following a rainstorm, run-off from impermeable areas is conveyed to the nearest watercourse,
- c) combined, where both domestic and industrial waste together with storm run-off are contained in one conduit, and
- d) culvert, where the watercourse is conveyed under a road, railway, etc.

The purpose of closed conduit systems types a), b) and c) is to remove waste products from urban areas to a site where treatment (mechanical, chemical and/or biological) can be undertaken. The cheapest way of conveying sewage in a conduit is by laying the conduit so that it follows the natural topography, while providing sufficient gradient where necessary so that sewage will not stagnate but will flow under gravity. In very flat areas conduits may have to be laid at great depths to attain a sufficient hydraulic gradient, or alternately, if they are laid at shallow depths, pumping/lifting stations may have to be incorporated.

At times of heavy rainfall, systems of type b) may become surcharged (i.e. full pipe flow). Therefore, overflows are constructed to convey the excess water to the nearest watercourse or storage area, thus relieving the surcharge and avoiding the chances of surface flooding.

Conduits may be constructed as closed or open, and may be made of various materials such as vitreous clayware, concrete, asbestos cement, cast iron, brick and, more recently, plastic and resin-bonded materials. They may range in diameter from 150 mm upwards, although it is rare, except in large cities, to have conduits greater than 3 m in diameter.

Sewage consists of floating and suspended solids and may contain effluents of a corrosive nature. In addition, the atmosphere within the closed conduit system may contain both inflammable and corrosive gases. Thus the total environment within the closed conduit system may be described as hostile.

ν

A flow-meter will have to operate in these hostile conditions over a wide range of flows, from free surface open channel flow to conduit full pressure flow. The nature of urban drainage is such that steady flow conditions are rare except near the outfall from large catchment areas where flow attenuation has occurred. Non-uniform flow also occurs as a result of bends, junctions and displaced joints.

The access to any closed conduit system is limited to the outfall or to specially built access points (i.e. manholes). Manholes are sited at irregular intervals where the sewer changes in direction or gradient or at a junction. These sites are hydraulically unsatisfactory for discharge measurement. Within the channel at a manhole an additional difficulty may be encountered when the depth of flow is above half-pipe full as the construction of the manhole frequently allows for benching to enable workmen to stand within the manhole. When the depth of flow rises above half-pipe full, the change in cross-sectional area of the closed conduit is discontinuous.

Mis oocum

It is recommended that in deep conduits a platform or gallery be constructed at vertical intervals of 10 m. This is for safety reasons when Indige pable of the second sec ascending and descending into manholes. Thus, the sensing and recording elements need not be more than 10 m apart, but they must be

age This page intentionally left blank

Measurement of free surface flow in closed conduits -

Part 1: Methods

1 Scope

This part of ISO/TR 9824 provides a synopsis of the methods of flow gauging that can be employed in closed conduits flowing part full and details the advantages and disadvantages of the various methods.

2 Normative reference

The following standard contains provisions which, through reference in this text, constitute provisions of this part of ISO/TR 9824. At the time of publication, the edition indicated was valid. All standards are subject to revision, and parties to agreements based on this part of ISO/TR 9824 are encouraged to investigate the possibility of applying the most recent edition of the standard indicated below. Members of IEC and ISO maintain registers of currently valid International Standards.

ISO 772:1988, Liquid flow measurement in open channels — Vocabulary and symbols.

3 Definitions

For the purposes of this part of ISO/TR 9824, the definitions given in ISO 772 and the following definitions apply.

3.1 permanent flow-meter: Flow-meter installed for a long period of time (in excess of about 12 months) and used to measure flow continuously or at discrete time intervals.

NOTE 1 The high costs incurred in the installation of these flow-meters may be tolerated as they are spread over a period of time.

The measurements provided may be used as the basis for an archive system to examine present trends, to forecast future trends and to determine daily operational requirements.

3.2 temporary flow-meter: Transportable flowmeter installed for a specific period of time (not more than about 12 months) and used to measure flow continuously or at discrete time intervals.

NOTE 2 The installation of the meter needs to be simple with minimal or no associated civil engineering costs.

3.3 portable flow-meter: Portable flow-meter used to obtain instantaneous measurements of flow or the velocity and depth components thereof.

4 Methods of flow measurement

There are two basic types of flow measurement known as direct measurement and indirect measurement.

4.1 Direct measurement

A direct measurement is one in which the flow is determined from measurements of various flow components, i.e. it is not inferred. The methods available for direct measurement are volumetric and dilution gauging.

4.1.1 Volumetric method

The volume of a receiving tank is known and all the flow is directed into this tank. The time for the tank to fill is recorded whence the average flow during the time taken to fill the tank may be calculated.

This method is usually not practical in an underground system.

In a system where a sump or wet-well has been constructed, and a pump is available to empty the sump, the flow can be measured by