RADIOAKTIIVSUSE MÕÕTMINE KESKKONNAS

Õhk: radoon-222

Osa 8: Esialgsete ja täiendavate uuringute metoodikad

hoonetes

Measurement of radioactivity in the environment

Air: radon-222

Part 8: Methodologies for initial and additional

investigations in buildings

(ISO 11665-8:2012)



EESTI STANDARDI EESSÕNA

NATIONAL FOREWORD

See Eesti standard EVS-ISO 11665-8:2014 "Radioaktiivsuse mõõtmine keskkonnas. Õhk: radoon-222. Osa 8: Esialgsete ja täiendavate uuringute metoodikad hoonetes" sisaldab rahvusvahelise standardi ISO 11665-8:2012 "Measurement of radioactivity in the environment – Air: radon-222 – Part 8: Methodologies for initial and additional investigations in buildings" identset ingliskeelset teksti.

Ettepaneku rahvusvahelise standardi ümbertrüki meetodil ülevõtuks on esitanud EVS/TK 28, standardi avaldamist on korraldanud Eesti Standardikeskus.

Standard EVS-ISO 11665-8:2014 on jõustunud sellekohase teate avaldamisega EVS Teataja 2014. aasta detsembrikuu numbris.

Standard on kättesaadav Eesti Standardikeskusest.

This Estonian Standard EVS-ISO 11665-8:2014 consists of the identical English text of the International Standard ISO 11665-8:2012 "Measurement of radioactivity in the environment – Air: radon-222 – Part 8: Methodologies for initial and additional investigations in buildings".

Proposal to adopt the International Standard by reprint method has been presented by EVS/TK 28, the Estonian standard has been published by the Estonian Centre for Standardisation.

This standard has been endorsed with a notification published in the official bulletin of the Estonian Centre for Standardisation.

The standard is available from the Estonian Centre for Standardisation.

Käsitlusala

Selles standardi ISO 11665 osas kehtestatakse nõuded radooni aktiivsuskontsentratsiooni määramiseks mis tahes hoonetes. Hooned võivad olla ühepereelamud, ühiskondlikud hooned, tööstushooned, maa-alused hooned jne.

Selles standardi ISO 11665 osas kirjeldatakse mõõtmismeetodeid, mida kasutatakse esialgse uurimise etapis hoonetes leiduva radooni aasta keskmise aktiivsuskontsentratsiooni hindamiseks. Samuti käsitletakse radooni allikate, sisenemisviiside ja levikuteedega seotud uuringuid (täiendavad uuringud).

Samuti kirjeldatakse selles standardi ISO 11665 osas nõudeid, mis kohalduvad rakendatud radooni leevendusmeetmete vahetule kasutusjärgsele testimisele, efektiivsuse kontrollimist, ning hoone käitumise stabiilsust radooni mõju suhtes.

Selles standardi ISO 11665 osas ei käsitleta ehitiste tehnilist kontrolli ega radooni leevendusmeetmete rakendamist.

Tagasisidet standardi sisu kohta on võimalik edastada, kasutades EVS-i veebilehel asuvat tagasiside vormi või saates e-kirja meiliaadressile standardiosakond@evs.ee.

ICS 13.040.01, 17.240

Standardite reprodutseerimise ja levitamise õigus kuulub Eesti Standardikeskusele

Andmete paljundamine, taastekitamine, kopeerimine, salvestamine elektroonsesse süsteemi või edastamine ükskõik millises vormis või millisel teel ilma Eesti Standardikeskuse kirjaliku loata on keelatud.

Kui Teil on küsimusi standardite autorikaitse kohta, võtke palun ühendust Eesti Standardikeskusega: Aru 10, 10317 Tallinn, Eesti; www.evs.ee; telefon 605 5050; e-post info@evs.ee

The right to reproduce and distribute standards belongs to the Estonian Centre for Standardisation

No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying, without a written permission from the Estonian Centre for Standardisation.

If you have any questions about copyright, please contact Estonian Centre for Standardisation:

Aru 10, 10317 Tallinn, Estonia; www.evs.ee; phone 605 5050; e-mail info@evs.ee

COI	ntents	Page
Fore	eword	iv
Intr	oduction	v
1	Scope	1
2	Normative references	1
3	Terms, definitions and symbols 3.1 Terms and definitions 3.2 Symbols	1
4	Organization of the measuring stages	4
5	Initial investigations 5.1 Objective	
6	Additional investigations 6.1 General 6.2 Methodology for additional investigations 6.3 Report of additional investigations	8 9
7	Immediate post-mitigation testing of the technical solutions applied	11
8	Control of the effectiveness of the technical solutions applied	12
9	Control of the sustainability	12
Ann	ex A (informative) Organization of radon measuring phases in a building	13
	ex B (informative) Examples of underground buildings and buried levels	
Ann	ex C (informative) Initial investigation report	15
Ann	ex D (informative) Example of analysis of initial investigation measurement results	18
Bibl	iography	19

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 11665-8 was prepared by Technical Committee ISO/TC 85, *Nuclear energy, nuclear technologies, and radiological protection*, Subcommittee SC 2, *Radiological protection*.

ISO 11665 consists of the following parts, under the general title *Measurement of radioactivity in the environment — Air: radon-222*:

- Part 1: Origins of radon and its short-lived decay products and associated measurement methods
- Part 2: Integrated measurement method for determining average potential alpha energy concentration of its short-lived decay products
- Part 3: Spot measurement method of the potential alpha energy concentration of its short-lived decay products
- Part 4: Integrated measurement method for determining average activity concentration using passive sampling and delayed analysis
- Part 5: Continuous measurement method of the activity concentration
- Part 6: Spot measurement method of the activity concentration
- Part 7: Accumulation method for estimating surface exhalation rate
- Part 8: Methodologies for initial and additional investigations in buildings

The following parts are under preparation:

- Part 9: Method for determining exhalation rate of dense building materials
- Part 10: Determination of diffusion coefficient in waterproof materials using activity concentration measurement
- Part 11: Test method for soil gas

Introduction

Radon isotopes 222 and 220 are radioactive gases produced by the disintegration of radium isotopes 226, and 224, which are decay products of uranium-238 and thorium-232 respectively, and are all found in the earth's crust. Solid elements, also radioactive, followed by stable lead are produced by radon disintegration [1].

Radon is today considered to be the main source of human exposure to natural radiation. The UNSCEAR (2008) report [2] suggests that, at the worldwide level, radon accounts for around 52 % of global average exposure to natural radiation. The radiological impact of isotope 222 (48 %) is far more significant than isotope 220 (4 %), while isotope 219 is considered negligible.

The International Cancer Research Centre (ICRC) of the World Health Organization (WHO) has recognized radon as a lung carcinogen in humans since 1987.

In this part of ISO 11665, the term radon refers to its isotope 222.

Radon activity concentration can vary from one to multiple orders of magnitude over time and space. Exposure to radon and its decay products varies tremendously from one area to another, as it depends on the amount of radon emitted by the soil, on the weather conditions, and on the degree of containment in the areas where individuals are exposed [3].

Radon activity concentration is usually higher in buildings than in the outside atmosphere due to the lower air renewal rates. The more the ventilation is reduced, the greater the accumulation of radon in buildings. The underlying soil is usually the dominant source of radon in buildings. Building materials, outside air, tap water and even city gas can also contribute to increasing radon activity concentration.

Radon enters buildings mainly via a convection mechanism, the so-called "stack effect" that is due to a difference in air temperature between the inside and the outside of the building, which generates a difference in pressure between the air in the building and the air contained in the underlying soil. The radon activity concentration depends on the architecture, equipment (chimney, mechanical ventilation systems, etc.) and the environmental parameters of the building (temperature, pressure, etc.) and on the occupants' lifestyle.

Radon activity concentrations vary inside buildings by several tens of becquerels per cubic metre to several hundreds of becquerels per cubic metre [4]. Activity concentration can be as high as several thousands of becquerels per cubic metre in very confined spaces.

The assessment of the radon activity concentration of the atmosphere in a building is based on a step-by-step procedure with two measuring stages: the initial investigation, to estimate the annual average value of the radon activity concentration in the building, and, when needed, additional investigations.

When it is decided that the radon activity concentration in a building has to be reduced, mitigation techniques will be adapted to each individual case [5][6][7]. The impact of the mitigation will be assessed using new radon measurements in the building.

NOTE The origin of radon-222 and its short-lived decay products in the atmospheric environment are described generally in ISO 11665-1 together with measurement methods.

Measurement of radioactivity in the environment — Air: radon-222 —

Part 8:

Methodologies for initial and additional investigations in buildings

1 Scope

This part of ISO 11665 specifies requirements for the determination of the activity concentration of radon in all types of buildings. The buildings can be single family houses, public buildings, industrial buildings, underground buildings, etc.

This part of ISO 11665 describes the measurement methods used to assess, during the initial investigation phase, the average annual activity concentration of radon in buildings. It also deals with investigations needed to identify the source, entry routes and transfer pathways of the radon in the building (additional investigations).

Finally, this part of ISO 11665 outlines the applicable requirements for the immediate post-mitigation testing of the implemented mitigation techniques, monitoring of their effectiveness and testing of the sustainability of the building's behaviour towards radon.

This part of ISO 11665 does not address the technical building diagnostic or the prescription of mitigation work.

2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 6707-1, Building and civil engineering — Vocabulary — Part 1: General terms

ISO 11665-1, Measurement of radioactivity in the environment — Air: radon-222 — Part 1: Origins of radon and its short-lived decay products and associated measurement methods

ISO 11665-4, Measurement of radioactivity in the environment — Air: radon-222 — Part 4: Integrated measurement method for determining average activity concentration using passive sampling and delayed analysis

3 Terms, definitions and symbols

3.1 Terms and definitions

For the purposes of this document, the terms and definitions given in ISO 11665-1 and ISO 6707-1 and the following apply.

3.1.1

additional investigations

stage of actions, including measurements, when identifying the sources of radon and its entry routes and transfer pathways in a building