

Measurement of radioactivity in the environment - Air: radon-222 - Part 7: Accumulation method for estimating surface exhalation rate (ISO 11665-7:2012)

## EESTI STANDARDI EESSÕNA

## NATIONAL FOREWORD

See Eesti standard EVS-EN ISO 11665-7:2015 sisaldab Euroopa standardi EN ISO 11665-7:2015 ingliskeelset teksti.	This Estonian standard EVS-EN ISO 11665-7:2015 consists of the English text of the European standard EN ISO 11665-7:2015.
Standard on jõustunud sellekohase teate avaldamisega EVS Teatajas.	This standard has been endorsed with a notification published in the official bulletin of the Estonian Centre for Standardisation.
Euroopa standardimisorganisatsioonid on teinud Euroopa standardi rahvuslikele liikmetele kättesaadavaks 16.09.2015.	Date of Availability of the European standard is 16.09.2015.
Standard on kättesaadav Eesti Standardikeskusest.	The standard is available from the Estonian Centre for Standardisation.

Tagasisidet standardi sisu kohta on võimalik edastada, kasutades EVS-i veebilehel asuvat tagasiside vormi või saates e-kirja meiliaadressile [standardiosakond@evs.ee](mailto:standardiosakond@evs.ee).

ICS 17.240

Standardite reprodutseerimise ja levitamise õigus kuulub Eesti Standardikeskusele

Andmete paljundamine, taastekitamine, kopeerimine, salvestamine elektroonsesse süsteemi või edastamine ükskõik millises vormis või millisel teel ilma Eesti Standardikeskuse kirjaliku loata on keelatud.

Kui Teil on küsimusi standardite autorikaitse kohta, võtke palun ühendust Eesti Standardikeskusega:

Aru 10, 10317 Tallinn, Eesti; koduleht [www.evs.ee](http://www.evs.ee); telefon 605 5050; e-post [info@evs.ee](mailto:info@evs.ee)

The right to reproduce and distribute standards belongs to the Estonian Centre for Standardisation

No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying, without a written permission from the Estonian Centre for Standardisation.

If you have any questions about copyright, please contact Estonian Centre for Standardisation:

Aru 10, 10317 Tallinn, Estonia; homepage [www.evs.ee](http://www.evs.ee); phone +372 605 5050; e-mail [info@evs.ee](mailto:info@evs.ee)

Measurement of radioactivity in the environment - Air:  
radon-222 - Part 7: Accumulation method for estimating  
surface exhalation rate (ISO 11665-7:2012)

Mesurage de la radioactivité dans l'environnement -  
Air: radon 222 - Partie 7: Méthode d'estimation du flux  
surfaccique d'exhalation par la méthode d'accumulation  
(ISO 11665-7:2012)

Ermittlung der Radioaktivität in der Umwelt - Luft:  
Radon-222 - Teil 7: Anreicherungsverfahren zur  
Abschätzung der Oberflächenexhalationsrate (ISO  
11665-7:2012)

This European Standard was approved by CEN on 12 June 2015.

CEN members are bound to comply with the CEN/CENELEC Internal Regulations which stipulate the conditions for giving this European Standard the status of a national standard without any alteration. Up-to-date lists and bibliographical references concerning such national standards may be obtained on application to the CEN-CENELEC Management Centre or to any CEN member.

This European Standard exists in three official versions (English, French, German). A version in any other language made by translation under the responsibility of a CEN member into its own language and notified to the CEN-CENELEC Management Centre has the same status as the official versions.

CEN members are the national standards bodies of Austria, Belgium, Bulgaria, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, Former Yugoslav Republic of Macedonia, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turkey and United Kingdom.



EUROPEAN COMMITTEE FOR STANDARDIZATION  
COMITÉ EUROPÉEN DE NORMALISATION  
EUROPÄISCHES KOMITEE FÜR NORMUNG

CEN-CENELEC Management Centre: Avenue Marnix 17, B-1000 Brussels

## European foreword

The text of ISO 11665-7:2012 has been prepared by Technical Committee ISO/TC 85 “Nuclear energy, nuclear technologies, and radiological protection” of the International Organization for Standardization (ISO) and has been taken over as EN ISO 11665-7:2015 by Technical Committee CEN/TC 430 “Nuclear energy, nuclear technologies, and radiological protection” the secretariat of which is held by AFNOR.

This European Standard shall be given the status of a national standard, either by publication of an identical text or by endorsement, at the latest by March 2016, and conflicting national standards shall be withdrawn at the latest by March 2016.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. CEN [and/or CENELEC] shall not be held responsible for identifying any or all such patent rights.

According to the CEN-CENELEC Internal Regulations, the national standards organizations of the following countries are bound to implement this European Standard: Austria, Belgium, Bulgaria, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, Former Yugoslav Republic of Macedonia, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turkey and the United Kingdom.

### Endorsement notice

The text of ISO 11665-7:2012 has been approved by CEN as EN ISO 11665-7:2015 without any modification.

# Contents

Page

<b>Foreword</b> .....	<b>iv</b>
<b>Introduction</b> .....	<b>v</b>
<b>1 Scope</b> .....	<b>1</b>
<b>2 Normative references</b> .....	<b>1</b>
<b>3 Terms, definitions and symbols</b> .....	<b>1</b>
<b>3.1 Terms and definitions</b> .....	<b>1</b>
<b>3.2 Symbols</b> .....	<b>2</b>
<b>4 Principle of the measurement method for estimating surface exhalation rate</b> .....	<b>2</b>
<b>5 Equipment</b> .....	<b>4</b>
<b>6 Accumulation of radon in a container</b> .....	<b>5</b>
<b>6.1 Accumulation characteristics</b> .....	<b>5</b>
<b>6.2 Accumulation duration</b> .....	<b>5</b>
<b>7 Sampling</b> .....	<b>5</b>
<b>7.1 Sampling objective</b> .....	<b>5</b>
<b>7.2 Sampling characteristics</b> .....	<b>5</b>
<b>7.3 Sampling duration</b> .....	<b>6</b>
<b>7.4 Volume of air sampled</b> .....	<b>6</b>
<b>8 Detection method</b> .....	<b>6</b>
<b>9 Measurement</b> .....	<b>6</b>
<b>9.1 Procedure</b> .....	<b>6</b>
<b>9.2 Influence quantities</b> .....	<b>7</b>
<b>10 Expression of results</b> .....	<b>7</b>
<b>10.1 Radon surface exhalation rate</b> .....	<b>7</b>
<b>10.2 Standard uncertainty</b> .....	<b>7</b>
<b>10.3 Decision threshold and detection limit</b> .....	<b>7</b>
<b>10.4 Limits of the confidence interval</b> .....	<b>8</b>
<b>11 Test report</b> .....	<b>8</b>
<b>Annex A (informative) Example of a sample results sheet</b> .....	<b>10</b>
<b>Annex B (informative) Estimation of radon surface exhalation rate using a continuous measurement method</b> .....	<b>12</b>
<b>Annex C (informative) Estimation of radon surface exhalation rate using a spot measurement method</b> .....	<b>18</b>
<b>Bibliography</b> .....	<b>23</b>

## Introduction

Radon isotopes 222, 220 and 219 are radioactive gases produced by the disintegration of radium isotopes 226, 224 and 223, which are decay products of uranium-238, thorium-232 and uranium-235 respectively, and are all found in the earth's crust. Solid elements, also radioactive, followed by stable lead are produced by radon disintegration<sup>[1]</sup>.

Radon is today considered to be the main source of human exposure to natural radiation. The UNSCEAR (2006) report<sup>[2]</sup> suggests that, at the worldwide level, radon accounts for around 52 % of global average exposure to natural radiation. The radiological impact of isotope 222 (48 %) is far more significant than isotope 220 (4 %), while isotope 219 is considered negligible. For this reason, references to radon in this part of ISO 11665 refer only to radon-222.

The radon-222 half-life (3,8 days) is long enough for it to migrate from the rock producing it, through the soil, to the air<sup>[3]</sup>. The radon atoms in the soil are produced by the disintegration of the radium-226 contained in the mineral grains in the medium. Some of these atoms reach the interstitial spaces between the grains: this is the phenomenon of emanation. Some of the atoms produced by emanation reach the soil's surface by diffusion and convection: this is the phenomenon of exhalation<sup>[3][4][5]</sup>. These mechanisms are also brought into play in materials (building materials, walls, etc.).

The quantity of radon-222 reaching the open air per unit of time and per unit of surface is called the radon-222 surface exhalation rate and depends on the physical characteristics of the soil and weather conditions. When the ground is covered in snow or a layer of water, or is frozen, this surface exhalation rate can become very weak.

Values of the radon-222 surface exhalation rate observed in France, for example, vary between 1 mBq/m<sup>2</sup>/s and about 100 mBq/m<sup>2</sup>/s<sup>[6][7]</sup>. In uranium-bearing ground, radon-222 surface exhalation rates in the order of 50 000 mBq/m<sup>2</sup>/s can be observed. By way of comparison, the United Nations Scientific Committee estimates the average surface exhalation rate on the surface of the globe at 20 mBq/m<sup>2</sup>/s<sup>[8]</sup>.

NOTE The origin of radon-222 and its short-lived decay products in the atmospheric environment and other measurement methods are described generally in ISO 11665-1.

# Measurement of radioactivity in the environment — Air: radon-222 —

## Part 7: Accumulation method for estimating surface exhalation rate

### 1 Scope

This part of ISO 11665 gives guidelines for estimating the radon-222 surface exhalation rate over a short period (a few hours), at a given place, at the interface of the medium (soil, rock, laid building material, walls, etc.) and the atmosphere. This estimation is based on measuring the radon activity concentration emanating from the surface under investigation and accumulated in a container of a known volume for a known duration.

This method is estimative only, as it is difficult to quantify the influence of many parameters in environmental conditions. This part of ISO 11665 is particularly applicable, however, in case of an investigation, a search for sources or a comparative study of exhalation rates at the same site. This part of ISO 11665 does not cover calibration conditions for the rate estimation devices.

The measurement method described is applicable for radon exhalation rates greater than 5 mBq/m<sup>2</sup>/s.

**NOTE** The uncertainty relating to the estimation of the result obtained by applying this part of ISO 11665 cannot guarantee that the true flux value is included in the uncertainty domain.

### 2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 11665-1, *Measurement of radioactivity in the environment — Air: radon-222 — Part 1: Origins of radon and its short-lived decay products and associated measurement methods*

ISO 11665-5, *Measurement of radioactivity in the environment — Air: radon-222 — Part 5: Continuous measurement method of the activity concentration*

ISO 11665-6, *Measurement of radioactivity in the environment — Air: radon-222 — Part 6: Spot measurement method of the activity concentration*

ISO/IEC 17025, *General requirements for the competence of testing and calibration laboratories*

IEC 61577-1, *Radiation protection instrumentation — Radon and radon decay product measuring instruments — Part 1: General principles*

### 3 Terms, definitions and symbols

#### 3.1 Terms and definitions

For the purposes of this document, the terms and definitions given in ISO 11665-1 and the following apply.

##### 3.1.1

##### **accumulation container**

recipient with known geometric characteristics used to accumulate the radon, with one open face in contact with the surface under investigation

### 3.1.2

#### **accumulation duration**

time elapsed between installation of the container after air tightness is achieved and the end of sampling

### 3.1.3

#### **back diffusion**

mechanism responsible for the transport of radon from the accumulation container atmosphere into the material under investigation

### 3.1.4

#### **effective surface**

internal surface of the open face of the container that is in contact with the surface under investigation

### 3.1.5

#### **effective volume**

available internal volume for radon accumulation after the container is installed

## 3.2 Symbols

For the purposes of this document, the symbols given in ISO 11665-1 and the following apply.

$C$	activity concentration in the accumulation container at time $t$ , in becquerels per cubic metre
$S$	effective surface, in square metres
$t$	elapsed time since the start of the accumulation process, in seconds
$U$	expanded uncertainty calculated by $U = k \cdot u(\ )$ with $k = 2$
$u(\ )$	standard uncertainty associated with the measurement result
$u_{\text{rel}}(\ )$	relative standard uncertainty
$V$	effective volume, in cubic metres
$\lambda_B$	time constant of back diffusion, per second
$\lambda_i$	decay constant of the nuclide $i$ , per second
$\lambda_V$	time constant of leakage, per second
$\phi$	surface exhalation rate, in becquerels per square metre per second
$\phi^*$	decision threshold of the surface exhalation rate, in becquerels per square metre per second
$\phi^\#$	detection limit of the surface exhalation rate, in becquerels per square metre per second
$\phi^\triangleleft$	lower limit of the confidence interval of the surface exhalation rate, in becquerels per square metre per second
$\phi^\triangleright$	upper limit of the confidence interval of the surface exhalation rate, in becquerels per square metre per second

## 4 Principle of the measurement method for estimating surface exhalation rate

The measurement method for estimating the radon surface exhalation rate is based on the following elements:

- accumulating radon in a radon-free accumulation container applied to the surface under investigation for a known duration;



- b) sampling a volume of air representative of the air contained in the accumulation container;
- c) measuring the radon activity concentration in this air sample;
- d) calculating the surface exhalation rate.

An estimate of the surface exhalation rate is calculated from the following elements:

- the variation in the radon activity concentration inside the accumulation container between two given moments;
- the effective surface of the accumulation container in contact with the surface under investigation;
- the effective volume of the accumulation container.

The radon activity concentration in the accumulation container increases over time depending on the surface-related exhalation rate, the volume of the accumulation container and influencing factors such as inadequate air tightness (leakage) and back diffusion.

The increase of radon activity concentration can be fitted with an exponential function:


$$C(t) = \frac{\phi \cdot S}{V \cdot \lambda} \cdot (1 - e^{-\lambda t}) \quad (1)$$

where

$$\lambda = \lambda_{\text{Rn222}} + \lambda_B + \lambda_V \quad (2)$$

Since the background radon activity concentration in the container is close to zero at the beginning of the accumulation process, the initial slope of the curve is independent of back diffusion<sup>[9][10]</sup>. Assuming that radon loss by leakage is negligible, the accumulation phase can be approximated by a linear increase of radon activity concentration in the accumulation container (see the example in Figure 1) as described by Formula (3):

$$C(t) = \frac{\phi \cdot S}{V} \cdot t \quad (3)$$



**Figure 1 — Example of changes in radon activity concentration in the accumulation container**

For outdoor measurements, the analysis of the measurement results can require detailed knowledge of climatic conditions. For example, the radon surface exhalation rate measurements carried out during snow or rain are only representative of these weather conditions.

For soil investigations, the surface area, topography, geology, pedology, vegetation, etc. all need to be taken into account. The humidity content of the ground at the time of sampling may be determined (see ISO 11465).


Several measurement methods meet the requirements of this part of ISO 11665. They can be distinguished by the way the air is sampled from the accumulation container.

## 5 Equipment

The apparatus shall include the following components.

- a) An accumulation container with known geometric characteristics (see Figure 2): The accumulation container characteristics shall be chosen so that any irregularities of the surface under investigation do not introduce an uncertainty of more than 10 % into the effective volume of the accumulation container. The effective surface of the accumulation container shall be selected to ensure that measurements are the most representative possible of the surface under investigation (i.e. the effective surface shall be appropriate for the surface area under investigation). The effective volume of the accumulation container shall be at least 10 times greater than the volume of air sampled from the accumulation container by the radon measuring device. The material used in the accumulation container shall not allow the radon to be diffused towards the outside of the container during the accumulation period. Neither the accumulation container material nor colour shall encourage a rise in temperature in the effective volume in the event of exposure to sunlight. The accumulation container shall have one or two orifices with a closing system for sampling purposes. When the accumulation container is placed on the material under investigation these orifices shall be open to prevent overpressure in the container.
- b) A homogenization system in the accumulation container: Depending on its dimensions, the container may have a system to homogenize the entire volume of the container.
- c) An air sampling device.
- d) A measuring device adapted to the physical quantity to be measured.

The necessary equipment for specific measurement methods is specified in Annexes B and C.



### Key

- 1 measuring device
- 2 accumulation container
- 3 effective volume
- 4 contact surface
- 5 effective surface

**Figure 2 — Example set-up of apparatus**

A single model of accumulation container shall be used when investigating a site in order to find the zones with the highest exhalation rates.