# INTERNATIONAL STANDARD

ISO 14397-1

> Second edition 2007-09-15

# Earth-moving machinery — Loaders and backhoe loaders —

### Part 1:

Calculation of rated operating capacity and test method for verifying calculated tipping load

Engins de terrassement — Chargeuses et chargeuses-pelleteuses —

Partie 1: Calcul de la charge utile nominale et méthode d'essai pour vérifier la charge de basculement calculée




#### PDF disclaimer

This PDF file may contain embedded typefaces. In accordance with Adobe's licensing policy, this file may be printed or viewed but shall not be edited unless the typefaces which are embedded are licensed to and installed on the computer performing the editing. In downloading this file, parties accept therein the responsibility of not infringing Adobe's licensing policy. The ISO Central Secretariat accepts no liability in this area.

Adobe is a trademark of Adobe Systems Incorporated.

Details of the software products used to create this PDF file can be found in the General Info relative to the file; the PDF-creation parameters were optimized for printing. Every care has been taken to ensure that the file is suitable for use by ISO member bodies. In the unlikely event that a problem relating to it is found, please inform the Central Secretariat at the address given below





#### COPYRIGHT PROTECTED DOCUMENT

#### © ISO 2007

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office Case postale 56 • CH-1211 Geneva 20 Tel. + 41 22 749 01 11 Fax + 41 22 749 09 47 E-mail copyright@iso.org Web www.iso.org

Published in Switzerland

Cont	tents	Page
Forew	vord	iv
1	Scope	1
2	Normative references	1
3	Terms and definitions	2
4	Symbols and abbreviated terms	
5	Requirement	
5.1	Calculation of rated operating capacity	4
5.2 5.3	Loader configurations	5
	Procedure for calculating tipping load at maximum reachreach	
6 6.1 6.2	Tipping load verification test	7
	General Test equipment	7 •
6.2 6.3	Test measurement of minimum tipping load	8
64	Verification	8
6.5	Test report	8
Annex	A (informative) Heavy single object (HSO)	15
Bibliog	Test report	17

#### **Foreword**

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in Maison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 14397-1 was prepared by Technical Committee ISO/TC 127, *Earth-moving machinery*, Subcommittee SC 1, *Test methods relating to machine performance*.

This second edition cancels and replaces the first edition (ISO 14397-1:2002), which has been technically revised.

ISO 14397 consists of the following parts, under the general title *Earth-moving machinery* — *Loaders and backhoe loaders*:

- Part 1: Calculation of rated operating capacity and test method for verifying calculated tipping load
- Part 2: Test method for measuring breakout forces and lift capacity to maximum lift height

# Earth-moving machinery — Loaders and backhoe loaders —

## Part 1:

Calculation of rated operating capacity and test method for verifying calculated tipping load

# 1 Scope

This part of ISO 14397 specifies the means for determining the rated operating capacity of wheeled or crawler loaders or of the loader portion of backhoe loaders, having buckets and material handling forks, as defined in ISO 6165. It gives standard methods for the calculation and test verification of the tipping load (mass).

It is applicable only to the use of buckets and forks on loaders.

NOTE Certain attachments can exceed the normal operating capacity and will require restricted machine operating conditions, such as reduced machine speed of lifting height. Refer to the attachment manufacturer's instructions for the intended use of the attachment.

#### 2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 6016:1998, Earth-moving machinery — Methods of measuring the masses of whole machines, their equipment and components

ISO 6165:2006, Earth-moving machinery — Basic types — Identification and terms and definitions

ISO 6746-1:2003, Earth-moving machinery — Definitions of dimensions and codes — Part 1: Base machine

ISO 7546:1983, Earth-moving machinery — Loader and front loading excavator buckets — Volumetric ratings

ISO 9248:1992, Earth-moving machinery — Units for dimensions, performance and capacities, and their measurement accuracies

ISO 14397-2, Earth-moving machinery — Loaders and backhoe loaders — Part 2: Test method for measuring breakout forces and lift capacity to maximum lift height

© ISO 2007 – All rights reserved